



Connect with Innovation™

ProSafe M5300 Managed Switches

Installation Guide

Start Here

Before you begin installation of your switch, check the package contents listed in the *Hardware Installation Guide* on the *Resource CD* that supports your switch. If any item is missing or damaged, contact your place of purchase.

Other documentation available on the *Resource CD* for your switch are the *Software Administration Guide*, and a *Command Line Interface Reference Manual*.

Follow these quick steps to install your switch. You can also consult the full *Hardware Installation Guide* for your switch on the *Resource CD*.

Set Up the Switch

Prepare the site so that the mounting, access, power source, and environmental requirements are met. If you have any questions about these requirements, see the *Hardware Installation Guide* for your switch on the *Resource CD*.

1. Install the switch using one of the following methods:

- On a flat surface: Put one of the rubber footpads that came with the switch on each of the four concave spaces on the bottom of the switch.
 - In a rack: Use the rack-mount kit supplied with your switch, following the installation instructions included with the kit.
2. Apply AC power. When you apply power, the Power LED blinks yellow as it conducts a power-on self-test (POST). After the switch passes the POST, the LED turns green. The switch is now functional.
- If the POST fails, the Power LED remains yellow (see “Troubleshooting” in the *Hardware Installation Manual* for assistance).

- If the Power LED does not light, check that the power cable is plugged in correctly and that the power source is good. If this does not resolve the problem, see “Troubleshooting” in the *Hardware Installation Guide*.

3. Connect devices to the switch.

- Use Category 5e (Cat5e) for copper ports at 1000 Mbps.
- Use NETGEAR AGM731F or AGM732F for fiber ports at 1000 Mbps.
- Use NETGEAR AFM735 for fiber ports at 100 Mbps.
- Use Category 6A (Cat6a) for copper ports at 10 Gbps.
- Use NETGEAR AXM761, AXM762, or AXM763 for fiber ports at 10 Gbps.

Note: Fiber SFP modules are shipped separately. If you need instructions on installing an SFP module, please refer to the *Hardware Installation Guide* on the *Resource CD*.

Note: In the room housing the switch, ensure that the ambient temperature does not exceed the specified operating temperature and that the environment is free of water condensation.

Perform the Initial Configuration

You can manage this switch through its web interface, or by using the command line interface (CLI) through a console port. This guide describes the web method. The CLI method is also described to determine a DHCP-assigned IP address or to use **ezconfig** to assign a static IP address. For web management, follow one of the following procedures, depending upon how your computer is set up.

- computer in DHCP client mode without DHCP server
- computer with static IP address
- computer in DHCP client mode with DHCP server

Computer in DHCP Client Mode without DHCP Server

WARNING!! If no DHCP server is present, the switch assumes a default IP address of 169.254.100.100 and a subnet mask of 255.255.0.0. The switch is in the same subnet used by a computer NIC port when in DHCP-client mode without a DHCP server present. Use this IP value to log in to the switch (see “Web Login to the Switch”).

Computer with Static IP Address

When the computer is in this mode, the switch also needs to be assigned a static IP address. To assign a static IP address, connect a VT100/ANSI terminal or a workstation to one of the switch’s console ports. A cable for the mini USB port is supplied.

1. Start a terminal emulation program (TEP) using the appropriate method for your operating system:

- Start a TEP. Windows users can use HyperTerminal.
- Windows Vista users should download a TEP from the Internet.
- Macintosh users can use ZTerm.
- UNIX users can use a terminal emulator such as TIP.

2. Select a console port using the console switch on the front panel:

- Select the mini USB port on the front panel (cable included) as the console port by pushing the slide switch to the left. Use the installation CD to install the USB driver on your computer.

Note: You might need to install the USB serial port driver available on the CD included with the package before you can use the USB port on the computer to connect to the switch.

- Select the DB9 (cable not included) on the rear panel as the console port by pushing the slide switch to the right.

3. Configure the TEP to use the following settings (written below the connector on the switch front panel):

- Baud rate: 115200 bps
- Data bits: 8
- Parity: none
- Stop bit: 1
- Flow control: none

4. At the command prompt **User:**, log in to the switch using the user name **admin**, and then press **Enter**. At the password prompt, press **Enter** again (no password is needed for initial configuration).

5. At the next command prompt, type **ezconfig** and press **Enter**.

6. The **ezconfig** utility is now running in the switch. Use it to set up your static IP address and subnet mask as shown in the example. Make sure that the selected switch IP address is in the same subnet as that of the computer.

```
User:admin
Password:
(switch) >ezconfig

NETGEAR EZ Configuration Utility
-----
Hello and Welcome!
This utility will walk you thru assigning the IP address for the switch management CPU. It will allow you to save the changes at the end. After the session, simply use the newly assigned IP address to access the Web GUI using any public domain Web browser.

Admin password not defined. Do you want to change the password? (Y/N/Q) n

The 'enable' password required for switch configuration via the command line interface is currently not configured. Do you wish to change it (Y/N/Q)? n

Assigning an IP address to your switch management

Current IP Address Configuration
-----
IP Address Assignment Mode: DHCP
IP Address: 0.0.0.0
Subnet mask: 0.0.0.0

Would you like to assign an IP address now? (Y/D/N/Q/?)
IP Address: 10.10.10.1
Network mask: 255.255.255.0

Do you want to assign switch name and location information (Y/N/Q)? n
There are changes detected, do you wish to save the changes permanently (Y/N)? y

The configuration changes have been saved successfully.
Please enter 'show running-config' to see the final configuration.

Thanks for using EzConfig!
```

7. Use this IP value to log in to the switch (see *Web Login to the Switch*).

For information about how to perform extensive CLI management, see both the *CLI Reference Manual* for your switch and the *Software Administration Guide*.

Computer in DHCP Client Mode with DHCP Server

By default, the switch is configured as a DHCP client to obtain its IP address from a DHCP server in the connected network. You need to access the switch from the serial console port.

1. Make sure that the switch is connected to a DHCP server.



201-15440-01



July 2012

2. Find the switch IP address assigned by the DHCP server.
 - a. Perform steps 1 through 3 of the procedure *Computer with Static IP Address*.
 - b. Type the **show network** command, and press **Enter**. A screen displays that shows the active switch IP address.
 - c. Use this IP address to log in to the switch through its web management interface (see *Web Login to the Switch*).


Web Login to the Switch

Use the appropriate IP address for your configuration to manage your switch through its web interface.

1. Type **http://<i>ipaddress</i>** into the URL field of your browser. A screen similar to the following displays.



2. Type **admin** for the user name, and leave the password field blank.
3. Click **Login**. The System Information screen display. You can now navigate from this point to configure your switch.



Technical Support

Thank you for selecting NETGEAR products.

After installing your device, locate the serial number on the label of your product and use it to register your product at <http://www.NETGEAR.com/register>. Registration is required before you can use the telephone support service.

Go to <http://support.netgear.com> for product updates, additional documentation, and support.

For complete DoC go to the NETGEAR EU Declarations of Conformity website at http://support.netgear.com/app/answers/detail/a_id/11621/.

For GNU General Public License (GPL) related information, please visit http://support.netgear.com/app/answers/detail/a_id/2649.

WARNING!!

Do not stack equipment, or place equipment in tight spaces, in drawers, or on carpets. Make sure your equipment is surrounded by at least 2 inches of air space.



This symbol was placed in accordance with the European Union Directive 2002/96 on the Waste Electrical and Electronic Equipment (the WEEE Directive). If disposed of within the European Union, this product should be treated and recycled in accordance with the laws of your jurisdiction implementing the WEEE Directive.

©2012 by NETGEAR, Inc. All rights reserved. NETGEAR and the NETGEAR logo are registered trademarks of NETGEAR, Inc. in the United States and/or other countries. Other brand and product names are trademarks or registered trademarks of their respective holders. Information is subject to change without notice.